




Manfrotto



INSTRUCTIONS

826

ASSEMBLAGE

Loosen the crick handle (20) and insert it onto the horizontal arm of the Studio Stand.

In case of difficulty, loosen the screws (22) and (23).


FUNCTION

Screw the camera onto the 3/8" screw (24) rotating the crown (17) after loosening the crick handle (19).

Rotation movements are achieved by loosening the crick handle (19).

Inclinations movements are achieved by loosening the crick handle (20).

The screws (22) and (23) may be regulated to improve the inclination movement, depending on the weight of the camera.

**MONTAGGIO**

Allentare la manopola a ripresa (20) ed inserire sul braccio orizzontale dello Studio Stand.

In caso di difficoltà allentare le due viti (22) e (23).

FUNZIONAMENTO

Avvitare la camera sulla vite da 3/8" (24) ruotando la ghiera (17) dopo aver allentato la manopola a ripresa (19).

Spostamenti in rotazione allentando la manopola a ripresa (19).

Spostamenti in inclinazione allentando la manopola a ripresa (20).

Le viti (22) e (23) possono essere regolate per migliorare, in base al peso della camera, il movimento di inclinazione.